

000007 06562500




FIG. 1



HORIZONTAL DIRECTION \_\_\_\_\_

**VERTICAL DIRECTION**

FIRST PASS PIN POSITION      SECOND PASS PIN POSITION




FIG. 3



HORIZONTAL DIRECTION →

VERTICAL DIRECTION ↓

FIRST PASS PIN POSITION SECOND PASS PIN POSITION




FIG. 5



## SECOND PASS PIN POSITION




FIG. 7








FIG. 9

RASTER LINE NO.	POSITION (INCH)	FIRST PASS PIN NO.	SECOND PASS PIN NO.
L4	5/120	#0	
L6	8/120		#0
L8	7/120		#1
L7	8/120	#2	
L8	8/120		#2
L9	9/120	#3	
L10	10/120		#3
L11	11/120		#4

FIG. 10




FIG. 11




FIG. 12




Fig. 13

